



RHINO-RACK

Rhino Nautic Kayak Loader Thule XSporter Fit NKL-FK4,5

Note: NKL - FK4 and NKL - FK5 sold as separate. Kits are dependant on type of XSporter bar purchased.

Important: Please read these instructions carefully prior to installation. Please refer to your fitting instruction to ensure that the roof racks are installed in the correct locations. Check the contents of kit before commencing fitment and report any discrepancies. Place these instructions in the vehicle's glove box after installation is complete.

Parts List NKL - FK4			
1	NKL Hook to suit Thule XSporter Bar	2	CA1336
2	M6x40 Security Screw	2	B085
3	M6 Nyloc Nut	2	N013
Parts List NKL -FK5			
5	NKL Hook to suit previous style Thule XSporter Bar	2	CA1400
2	M6x40 Security Screw	2	B085
3	M6 Nyloc Nut	2	N013
4	Fitting Instruction	1	R482

1 Using NKL XSporter hook as a guide, drill through the crossbar.

Thule XSporter Bar.

Previous style Thule XSporter Bar.

2 1: Place the hook into the end of the crossbar. 2: Push the nyloc nut into place into the c-channel on the underside of the bar. 3: Using a 5mm allen key, tighten hardware to 3-4Nm.

CA1336

Thule XSporter Bar.

CA1400

Previous style Thule XSporter Bar.

3 Be sure all hardware is secure before use.

Previous style Thule XSporter Bar.

Thule XSporter Bar.

Note for Dealers and Fitters:
 It is your responsibility to ensure these fitting instructions are given to the end user or client.
 Rhino-Rack
 3 Pike Street, Rydalmere,
 NSW 2116, Australia.
 (Ph) (02) 9638 4744
 (Fax) (02) 9638 4822

Document No: R482
 Prepared By: Kayle Everett
 Authorised By: Chris Murty

Issue No: 03
 Issue Date: 18/11/2014

These instructions remain the property of Rhino-Rack Australia Pty Ltd and may not be used or changed for any other purpose than intended.