


RCP93-BK Track Base Kit

Important:


- 1. Check the Rhino-Rack website to ensure you have the latest issue of these instructions.
- 2. Please refer to your fitting instruction to ensure that the roof racks are installed in the correct locations.
- 3. Check the contents of kit before commencing fitment and report any discrepancies.
- 4. Place these instructions in the vehicle's glove box after installation is complete.
- 5. These instructions must be followed for warranty to be upheld.

Fit Time: 15min



Carrying Capacity

Check your vehicle owners hand book for vehicle maximum carrying capacity. Please ensure you use the vehicle manufacturer's maximum tub allowance if it is lower than the figure listed below. Load must be evenly distributed over the system.



Warning

- Check part number or kit is correct for use with your vehicle.
- Do not attempt to fit the rack system to your vehicle unless you fully understand these fitting instructions. Please direct any questions regarding fitting to the dealer from where the roof racks were purchased.
- Always ensure you fasten your load securely.
- Use only non-stretch fastening ropes or straps to attach cargo to your load.

In service maintenance checks

- All bolt connections should be checked after driving a short distance when you first install your roof racks.
- All bolted connections should be checked again at regular intervals (weekly is recommended, depending on road conditions, usage, loads and distances travelled).
- All bolted connections should be checked each time they are re-fitted.
- Off-road conditions are more rigorous. Check all bolted connections and your load more regularly.
- Ensure that your vehicle manufacturer's GVM, and gross axle weights are not exceeded (refer to vehicle owner's manual).


Torque Settings:

Unless stated otherwise in these instructions, all fasteners should be set to the following torque settings:




Note for Dealers and Fitters


It is your responsibility to ensure these fitting instructions are given to the end user or client. These instructions remain the property of Rhino-Rack Australia Pty. Ltd. and may not be used or changed for any other purpose than intended.



| | Pa | arts Lis |
|--|------------------------------|----------|
| Item | Description | Qty |
| Α | M6 x 40mm Flanged Torx Bolt | 4 |
| В | M6 x 45mm Flanged Torx Bolt | 4 |
| С | *M6 X 16 X 1.6mm Flat Washer | 4 |
| D | Top Pad | 4 |
| E | Bottom Pad | 4 |
| F | Rubber Gasket | 4 |
| G | M6 Nut 24mm x 21mm x 4mm | 4 |
| Н | Instructions | 1 |
| Note Long and Crasshans are cald concrete Switchle for both DV2001 | | |

Note: Legs and Crossbars are sold separate. Suitable for both RX300H, RX300L, RCH, RCL, RVL and RVH legs. Be sure to obtain correct kits for your vehicle.





Instructions. 1 2 Proceed to complete the 'Fit My Vehicle' journey to Slide two M6 nuts into each track as shown ensure the correct bolts & washer (A / B / C) are used for your vehicle's tracks. 1. Complete Fit my vehicle journey 2. Select your Product Solution 3. Scroll down to 'Product Details' 4. Download instructions under the 'INSTRUCTIONS' tab rhinorack.com/root 3 4 Using the correct bolt for your tracks, install To ensure that the correct Flanged Torx bolt is legs into the M6 nuts ACTERIZED used, check the bolt length against the below 1:1 size check illustration. 10mm Socket / Spanner 6Nm В 4lbs/ft Α M6 x 45mm Flanged Torx Bolt M6 x 40mm Flanged Torx Bolt M6 x 40mm Flanged Torx Bolt В 46 x 45mm Flanged Torx Bolt С 0 M6 X 16 X 1.6 FLAT WASHER BLACK ("Washer only required for some fitments. Carefully check online "Fit My Vehicle" journey for the specific instructions to install to your vehicle's tracks. Failure to do so may cause damage to the tracks or vehicle.) 40mm 45mm D , **0** 1:1 Scale G A *Scale on A4 printed sized