

SPECIFICATION SHEET RSS119

TOYOTA
TARAGO
07/00 ON
50 KG

SPECIAL FITTING TIPS

Open both sliding doors and remove grey plastic bungs, you will find these located in side turret of the sliding doors. Place rubber pads onto roof(these are clearly marked left and right)fit clamps onto vehicle with M6 x 16 bolts making sure they locate with the rubber pads. Take cross bars and fit onto rubber pads, once this is completed you can now install M6 x 32 bolts and tighten. Please note there is a front and rear cross bar.

SPECIFICATIONS:

Front Bar – 91.5`

Rear Bar - 88.5

Manufactured By Rhino-Rack 3 Pike St Rydalmere, NSW 2116, Australia (Ph) 02 9638 4744 (Fax) 02 9638 4822

