



RHINO-RACK

Aerodynamic & Heavy Duty Roof Rack Systems

SPECIFICATION SHEET

RSS88

VEHICLE BRAND	TOYOTA
VEHICLE TYPE	TARAGO
YEAR MODEL	9/90 ON – NO SUNROOFS
LOAD RATING	50KG

SPECIAL FITTING TIPS

Open Passenger sliding door and drivers side and middle windows. Remove the two plastic bungs located in the side turret of the sliding door. Locate the two hooks on the drivers side, which are located behind the window. The roofrack clamps locate onto these hooks. Please note that the rear clamp has a notch on the top edge to indicate rear clamp. Place rubber pads on roof and locate clamp onto hook. If clamp is hard to hook on, splay hook apart with screwdriver. Repeat this operation on the rear bar. Always install drivers side clamps first. Attach straps clamps on passengers side using M6 X 16 bolts supplied. Ensure rubber pads are placed under them when installing clamps. Place crossbars on pads and tighten.

SPECIFICATIONS:

Front Bar – 970mm

Rear Bar – 950mm

PADS

Front right– Right standard

Front left – Left Astina modified

Figure 1

Rear right – Right standard

Rear left – Left Astina modified

CLAMPS

675 – Front left

677 - Front right

676 – Rear left – 1 notch

678 – Rear right – 1 notch

Manufactured By Rhino-Rack

3 Pike St Rydalmere,

NSW 2116, Australia

(Ph) 02 9638 4744

(Fax) 02 9638 4822



