


CONTROLLED



RHINO-RACK

Rhino-Rack High Back Chair (34003)



Maximum load capacity : 136kg/300lbs

Rhino-Rack

3 Pike Street, Rydalmere,
NSW 2116, Australia.
(Ph) (02) 9638 4744
(Fax) (02) 9638 4822

Issue No: R498
Prepared By: Kayle Everett
Authorised By: Chris Murty

Issue No: 02
Date: 26/02/2015

These instructions remain the property of Rhino-Rack Australia Pty Ltd and may not be used or changed for any other purpose than intended.





Rhino-Rack High Back Chair (34003)


Parts List

Item	Component Name	Qty	Part No.
1	High Back Chair	1	
2	Camping Chair Bag	1	
3	Fitting Instruction	1	R498

**MAX. weight :
136kg/300lbs**




1







Rhino-Rack High Back Chair (34003)

- 2** Hold two opposing legs on the front and back of the chair.



- 3** Push the opposing legs away from one another as shown. This will open the chair ready for use.



Storage pouches can be found on the right side of the chair.