





Fitting Chart - TOYOTA Land Cruiser 4dr 4WD200 Series

PIONEER 41108	(1828 x 1426mm)	(5' 11 31/32" x 4' 8 9/64")
PIONEER 42108B	(1828 x 1426mm)	(5' 11 31/32" x 4' 8 9/64")
PIONEER 45108B	(1828 x 1426mm)	(5' 11 31/32" x 4' 8 9/64")



Front of Tray



Front Crossbar			Middle Crossbar			Rear Crossbar			Approx. Overall Vehicle Height
Front Slot	Dim. A	Leg Height Spacer	Middle Slot	Dim. A	Leg Height Spacer	Rear Slot	Dim. A	Leg Height Spacer	
Drill Hole Ø8.5mm		QMHD05	Drill Hole Ø8.5mm		QMHD05	Drill Hole Ø8.5mm		QMHD05	

Country	Vehicle	Running Date	Vehicle Load Rating (kg / lbs)	Fit Kit
Australia & NZ	TOYOTA Land Cruiser 4dr 4WD 200 Series	11/07 - on	150 / 330	1 x RCP17-BK 1 x RCH6 3 x QMHD05
Canada, USA & South America	TOYOTA Land Cruiser 4dr SUV 200 Series	2008 - on		
South Africa	TOYOTA Land Cruiser 4dr SUV 200 Series	2011 - on		
UK & Europe	TOYOTA Land Cruiser 4dr 4WD 200 Series	11/07 - on		

Note for Dealers and Fitters:

It is your responsibility to ensure these fitting instructions are given to the end user or client

Rhino-Rack, 22 Hanson St, Eastern Creek

NSW 2766, Australia

(02) 8846 1900

rhinorack.com.au

These instructions remain the property of Rhino-Rack Australia Pty. Ltd. and may not be used or changed for any other purpose than intended.

Document No: R1557

Prepared By: Kayle Everett

Authorised By: Nicholas Clarke

Issue No: 02

Issue Date: 22/11/2018