

RHINO-RACK | PIONEER VEHICLE FITTING INFORMATION CONTROLLED


VEHICLE	PIONEER SIZE	CONNECTOR	HEIGHT ADDED (mm / in)
ISUZU MU-X LS-T 4WD/SUV Flush Rail 4 dr	52107	RLT600	

IMPORTANT NOTES

Flush rails to be removed following steps in instruction R715. - Do not operate sunroof

REGION	AUS	NZ	USA	CA	SA	UK	EU	ZA
AVAILABILITY	✓	✓	×	×	×	×	×	×
RUNNING DATES	12/13 -	12/13 -	-	-	-	-	-	-

UNDERBAR SPACING



Γ	VEHICLE LOAD LIM	IT (VLL)	SYSTEM WEIGHT	r (SW)	 	
	CONNECTOR	RLT600		RLT600	RLT600	
	SPACERS REQ'D	QMVA15 / QMW10			QMVA10	
	22	,			 00	

VEHICLE LOAD LIMIT (VLL) SYSTEM WEIGHT (SW) (kg / lbs) (kg / lbs)		ON-ROAD CARGO ALLOW. (OR)	OFF-ROAD CARGO ALLOW. (OFR)	
Up to 100 / 220.5 *	30 / 66.1	OR = VLL - SW	OFR = OR / 1.5	

*CHECK YOUR VEHICLE OWNERS HAND BOOK FOR VEHICLE MAXIMUM CARRYING CAPACITY. PLEASE ENSURE YOU USE THE VEHICLE MANUFACTURERS MAXIMUM ROOF ALLOWANCE IF IT IS LOWER THAN THE FIGURE LISTED IN THIS INSTRUCTION.

NOTES FOR DEALERS / FITTERS

It is your responsibility to ensure these fitting instructions are given to the end user or client.

Document No: R2296 Issue Date: 14-Apr-20

These instructions remain the property of Rhino-Rack Australia Pty. Ltd. and may not be used or changed for any other purpose than intended.

Page 1 of 1 rhinorack.com.au