

## RHINO-RACK | PIONEER NG VEHICLE FITTING INFORMATION


VEHICLE	PIONEER SIZE	CONNECTOR	HEIGHT ADDED (mm / in)
JEEP Wrangler JL 4WD/SUV 4dr	52108	RCL6	115.0 / 4.5

IMPO	RTAN	T NOT	ΓES

Position the centreline of the Pioneer evenly between mounting points of RJLB1

REGION	AUS	NZ	USA	CA	SA	UK	EU	ZA
AVAILABILITY	✓	✓	✓	✓	×	×	×	×
RUNNING DATES	01/19 -	01/19 -	2019 -	2019 -	-	-	-	-

## **UNDERBAR SPACING**



VEHICLE LOAD LIMIT (VLL) (kg / lbs)	SYSTEM WEIGHT (SW) (kg / lbs)	ON-ROAD CARGO ALLOW. (OR)	OFF-ROAD CARGO ALLOW. (OFR)
Up to 120 / 264.6*	33 / 72.1	OR = VLL - SW	OFR = OR / 1.5

\*CHECK YOUR VEHICLE OWNERS HAND BOOK FOR VEHICLE MAXIMUM CARRYING CAPACITY. PLEASE ENSURE YOU USE THE VEHICLE MANUFACTURERS MAXIMUM ROOF ALLOWANCE IF IT IS LOWER THAN THE FIGURE LISTED IN THIS INSTRUCTION.

## **NOTES FOR DEALERS / FITTERS**

It is your responsibility to ensure these fitting instructions are given to the end user or client.

Document No: R2434 Issue Date: 18-Feb-20

These instructions remain the property of Rhino-Rack Australia Pty. Ltd. and may not be used or changed for any other purpose than intended.

Page 1 of 1 rhinorack.com.au