




Rhino Rack 2500 Series - DK466M instruction

CROSSBAR IDENTIFICATION







VA crossbar

EURO crossbar

HD crossbar

| | | MIDDLE CROSSBAR | | | | | REAR CROSSBAR | | | | | | | |
|-----------------------------------|-------|-----------------|--------------------------|-------------------------|---|---|----------------------------------|--------|-------------------------|------------------------|---|---|----------------------------------|----------------------------------|
| | | | | | VA | EURO | ₽ HD | | | | VA | EURO | ₩ HD | |
| Vehicle | Date | Crossbar | Front Right Pad/Clamp | Front Left Pad/Clamp | Measurement strip length per side | Measurement strip length per side | Measurement Distance (x) | OFFOLK | Rear Right Pad/Clamp | Rear Left Pad/Clamp | Measurement strip length per side | Measurement strip length per side | Measurement Distance (x) | Foot plate arrow direction |
| KIA Picanto Gen 2 5dr Hatch | 2011- | 1180mm | M368 SUB0371 | M368 SUB0371 | 155mm | 100mm | 878mm / | OUT | - | - | | | | _ |
| | | | Pad Arrow OUT | | 13311111 | 10011111 | 34,9/16" | 001 | | - | - | - | - | |



Rhino Rack 2500 Series - DK466M instruction


Measurement A: CENTRE of door jamb to CENTRE arrow of leg foot plate.


Measurement B: CENTRE of Front leg foot plate arrow to CENTRE of Rear leg foot plate arrow.

Carrying capacity: Roof rack is rated up to 75kg. Please refer to manufacturers handbook for your vehicles maximum roof load capacity. Always use the lower of the two figures.

If your vehicle is not listed on this fitting instruction please refer to your countries Rhino-Rack web site for the latest information.

Direction of Pad Arrow and Foot Plate Arrow





| VEHICLE | Date | Measurement A | Measurement B | Load Rating up to (includes racks 5kg/ 11lbs) | | |
|-----------------------------|--------|---------------|---------------|--|--|--|
| KIA Picanto Gen 2 5dr Hatch | 2011 - | 0mm / 0" | - | 30kg / 66lbs | | |