




VEHICLE	KIT	CROSSBAR
Infiniti JX35 5dr SUV	DK339	SZ137
RUNNING DATES	13-13	
VEHICLE NOTES		

VISIT THE ONLINE
CALCULATOR FOR CURRENT
SYSTEM LOAD LIMIT DATA



DYNAMIC ROAD LOAD LIMIT (NOTE: DIFFERENT ON AND OFF ROAD CARGO LIMIT)
***USE THE VEHICLE MANUFACTURER'S MAXIMUM ROOF ALLOWANCE IF IT IS LOWER THAN THE FIGURE LISTED**


 LOAD LIMIT	 SYSTEM WEIGHT	 ON ROAD CARGO LIMIT	 OFF ROAD CARGO LIMIT (ON ROAD CARGO LIMIT / 2)
UP TO 75 kg * 165 lb	— 5 kg 11lb	= UP TO 70 kg 154 lb	OR UP TO 35 kg 77 lb

PAD AND CLAMP DETAILS


<p>PLATE ID: M311</p> <p>PAD ID: M503</p>	<p>CLAMP ID: SUB0148</p>	<p>PLATE ID: M311</p> <p>PAD ID: M504</p>
<p>PLATE ID: M311</p> <p>PAD ID: M366</p>	<p>CLAMP ID: SUB0151</p>	<p>PLATE ID: M311</p> <p>PAD ID: M366</p>

Diagram of a car roof showing the installation positions: FL (Front Left), FR (Front Right), RL (Rear Left), RR (Rear Right), and REAR (center). The car is oriented with FRONT at the top and REAR at the bottom. The roof is divided into 'OUT' (outer) and 'IN' (inner) sections.

MEASUREMENT STRIPS



VEHICLE POSITIONING



NOTES FOR DEALERS / FITTERS

It is your responsibility to ensure these fitting instructions are given to the end user or client.

Document No: R4525
Issue No: 1
Issue Date: 6-Jan-25